


Welcome

Welcome to the world of Motorola digital wireless communications! We are pleased that you have chosen the Motorola V220 GSM wireless phone.



www.hellomoto.com

MOTOROLA and the Stylised M Logo are registered in the US Patent & Trademark Office.

Java and all other Java-based marks are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and other countries.

All other product or service names are the property of their respective owners.

© Motorola, Inc., 2003.

Software Copyright Notice

The Motorola products described in this manual may include copyrighted Motorola and third-party software stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Motorola and third-party software providers certain exclusive rights for copyrighted software, such as the exclusive rights to distribute or reproduce the copyrighted software. Accordingly, any copyrighted software contained in the Motorola products may not be modified, reverse-engineered, distributed, or reproduced in any manner to the extent allowed by law. Furthermore, the purchase of the Motorola products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any licence under the copyrights, patents, or patent applications of Motorola or any third-party software provider, except for the normal, non-exclusive, royalty-free licence to use that arises by operation of law in the sale of a product.

While Products specifications and features may be subject to change without notice, we are making every possible effort to ensure that user manuals are updated on a regular basis to reflect product functionality revisions. However, in the unlikely event that your manual version does not fully reflect the core functionality of your product, please let us know. You may also be able to access up-to-date versions of our manuals in the consumer section of our Motorola web site, at <http://www.motorola.com>.

Contents

Safety and General Information	6
Getting Started	13
About This Guide	13
Installing the SIM Card	13
Battery Use	14
Installing the Battery	16
Charging the Battery	17
Turning Your Phone On	18
Adjusting Volume	18
Making a Call	19
Answering a Call	19
Viewing Your Phone Number	20
Highlight Features	21
Taking and Sending a Photo	21
Sending a Multimedia Message	23
Receiving a Multimedia Message	25
Playing Video Clips	26
Learning to Use Your Phone	27
Using the Display	27
Using the 5-Way Navigation Key	32
Using Menus	33
Entering Text	36
Using the Smart Key	45
Using the External Display	45
Using the Handsfree Speaker	46
Changing a Code, PIN, or Password	46

Locking and Unlocking Your Phone	47
If You Forget a Code, PIN, or Password	48
Using the Phonebook	49
Setting Up Your Phone	51
Storing Your Name and Phone Number	51
Setting the Time and Date	51
Setting a Ring Style	52
Setting Answer Options	52
Setting a Wallpaper Image	53
Setting a Screen Saver Image	54
Setting Display Contrast	55
Setting Display Colour	55
Adjusting the Backlight	55
Setting Display Timeout	56
Calling Features	57
Changing the Active Line	57
Redialling a Number	57
Using Automatic Redial	58
Using Caller ID	58
Cancelling an Incoming Call	59
Turning Off a Call Alert	59
Calling an Emergency Number	59
Dialling International Numbers	60
Viewing Recent Calls	60
Returning an Unanswered Call	62
Using the Notepad	62
Attaching a Number	63
Calling With Speed Dial	63
Calling With 1-Touch Dial	63
Using Voicemail	64

Using Call Waiting65
Putting a Call On Hold66
Transferring a Call66
Phone Features68
Menu Map68
Feature Quick Reference.70
Specific Absorption Rate Data85
Index87

Safety and General Information

IMPORTANT INFORMATION ON SAFE AND EFFICIENT OPERATION. READ THIS INFORMATION BEFORE USING YOUR PHONE.

The information provided in this document supersedes the general safety information in user guides published prior to December 1, 2002.

Exposure To Radio Frequency (RF) Energy

Your phone contains a transmitter and a receiver. When it is ON, it receives and transmits RF energy. When you communicate with your phone, the system handling your call controls the power level at which your phone transmits.

Your Motorola phone is designed to comply with local regulatory requirements in your country concerning exposure of human beings to RF energy.

Operational Precautions

To assure optimal phone performance and make sure human exposure to RF energy is within the guidelines set forth in the relevant standards, always adhere to the following procedures.

External Antenna Care

Use only the supplied or Motorola-approved replacement antenna. Unauthorised antennas, modifications, or attachments could damage the phone.

Do NOT hold the external antenna when the phone is IN USE. Holding the external antenna affects call quality and may cause the phone to operate at a higher power level than needed. In addition, use of unauthorised antennas may result in non-compliance with the local regulatory requirements in your country.

Phone Operation

When placing or receiving a phone call, hold your phone as you would a wireline telephone.

Body-Worn Operation

To maintain compliance with RF energy exposure guidelines, if you wear a phone on your body when transmitting, always place the phone in a Motorola-supplied or approved clip, holder, holster, case, or body harness for this phone, if available. Use of accessories not approved by Motorola may exceed RF energy exposure guidelines. If you do not use one of the body-worn accessories approved or supplied by Motorola, and are not using the phone held in the normal use position, ensure the phone and its antenna are at least 1 inch (2.5 centimetres) from your body when transmitting.

Data Operation

When using any data feature of the phone, with or without an accessory cable, position the phone and its antenna at least 1 inch (2.5 centimetres) from your body.

Approved Accessories

Use of accessories not approved by Motorola, including but not limited to batteries and antenna, may cause your phone to exceed RF energy exposure guidelines. For a list of approved Motorola accessories, visit our website at www.Motorola.com.

RF Energy Interference/Compatibility

***Note:** Nearly every electronic device is susceptible to RF energy interference from external sources if inadequately shielded, designed, or otherwise configured for RF energy compatibility. In some circumstances your phone may cause interference.*

Facilities

Turn off your phone in any facility where posted notices instruct you to do so. These facilities may include hospitals or health care facilities that may be using equipment that is sensitive to external RF energy.

Aircraft

When instructed to do so, turn off your phone when on board an aircraft. Any use of a phone must be in accordance with applicable regulations per airline crew instructions.

Medical Devices

Pacemakers

Pacemaker manufacturers recommend that a minimum separation of 6 inches (15 centimetres) be maintained between a handheld wireless phone and a pacemaker.

Persons with pacemakers should:

- ALWAYS keep the phone more than 6 inches (15 centimetres) from your pacemaker when the phone is turned ON.
- NOT carry the phone in the breast pocket.
- Use the ear opposite the pacemaker to minimise the potential for interference.
- Turn OFF the phone immediately if you have any reason to suspect that interference is taking place.

Hearing Aids

Some digital wireless phones may interfere with some hearing aids. In the event of such interference, you may want to consult your hearing aid manufacturer to discuss alternatives.

Other Medical Devices

If you use any other personal medical device, consult the manufacturer of your device to determine if it is adequately shielded from RF energy. Your GP may be able to assist you in obtaining this information.

Use While Driving

Check the laws and regulations on the use of phones in the area where you drive. Always obey them.

When using your phone while driving, please:

- Give full attention to driving and to the road.
- Use hands-free operation, if available.
- Pull off the road and park before making or answering a call if driving conditions so require.

Operational Warnings

For Vehicles With an Air Bag

Do not place a phone in the area over an air bag or in the air bag deployment area. Air bags inflate with great force. If a phone is placed in the air bag deployment area and the air bag inflates, the phone may be propelled with great force and cause serious injury to occupants of the vehicle.

Potentially Explosive Atmospheres

Turn off your phone prior to entering any area with a potentially explosive atmosphere, unless it is a phone type especially qualified for use in such areas and certified as “Intrinsically Safe.” Do not remove, install, or charge batteries in such areas. Sparks in a potentially explosive atmosphere can cause an explosion or fire resulting in bodily injury or even death.

Note: *The areas with potentially explosive atmospheres referred to above include fuelling areas such as below decks on boats, fuel or chemical transfer or storage facilities, areas where the air contains chemicals or particles, such as grain, dust, or metal powders. Areas with potentially explosive atmospheres are often but not always posted.*






Blasting Caps and Areas

To avoid possible interference with blasting operations, turn OFF your phone when you are near electrical blasting caps, in a blasting area, or in areas posted “Turn off electronic devices.” Obey all signs and instructions.

Batteries

Batteries can cause property damage and/or bodily injury such as burns if a conductive material such as jewellery, keys, or beaded chains touch exposed terminals. The conductive material may complete an electrical circuit (short circuit) and become quite hot. Exercise care in handling any charged battery, particularly when placing it inside a pocket, bag, or other container with metal objects. **Use only Motorola original batteries and chargers.**

Your battery or phone may contain symbols, defined as follows:

Symbol	Definition
	Important safety information will follow.
	Your battery or phone should not be disposed of in a fire.
	Your battery or phone may require recycling in accordance with local laws. Contact your local regulatory authorities for more information.
	Your battery or phone should not be thrown in the trash.
	Your phone contains an internal lithium ion battery.

Seizures/Blackouts

Some people may be susceptible to epileptic seizures or blackouts when exposed to blinking lights, such as when watching television

or playing video games. These seizures or blackouts may occur even if a person never had a previous seizure or blackout.

If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult with your doctor before playing video games on your phone or enabling a blinking-lights feature on your phone. (The blinking-light feature is not available on all products.)

Parents should monitor their children's use of video game or other features that incorporate blinking lights on the phones. All persons should discontinue use and consult a doctor if any of the following symptoms occur: convulsion, eye or muscle twitching, loss of awareness, involuntary movements, or disorientation.

To limit the likelihood of such symptoms, please take the following safety precautions:

- Do not play or use a blinking-lights feature if you are tired or need sleep.
- Take a minimum of a 15-minute break hourly.
- Play in a room in which all lights are on.
- Play at the farthest distance possible from the screen.

Repetitive Motion Injuries

When you play games on your phone, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your body. Follow these instructions to avoid problems such as tendonitis, carpal tunnel syndrome, or other musculoskeletal disorders:


- Take a minimum 15-minute break every hour of game playing.
- If your hands, wrists, or arms become tired or sore while playing, stop and rest for several hours before playing again.
- If you continue to have sore hands, wrists, or arms during or after play, stop playing and see a doctor.

European Union Directives Conformance Statement

Hereby, Motorola declares that this product is in compliance with



- The essential requirements and other relevant provisions of Directive 1999/5/EC
- All other relevant EU Directives



The above gives an example of a typical Product Approval Number.

You can view your product's Declaration of Conformity (DoC) to Directive 1999/5/EC (the R&TTE Directive) at www.motorola.com/rtte - to find your DoC, enter the product Approval Number from your product's label in the "Search" bar on the Web site

Getting Started

About This Guide

This guide describes the basic features of your Motorola wireless phone.

Optional Features



This label identifies an optional network, SIM card, or subscription-dependent feature that may not be offered by all service providers in all geographical areas. Contact your service provider for more information.

Optional Accessories







This label identifies a feature that requires an optional Motorola Original™ accessory.

Installing the SIM Card

Your SIM (Subscriber Identity Module) card contains your phone number, service details, and phonebook/message memory.

Caution: Do not bend or scratch your SIM card. Avoid exposing your SIM card to static electricity, water, or dirt.



Battery Use

Battery performance depends on many factors, including your wireless carrier's network configuration; signal strength; the temperature at which you operate your phone; the features and/or settings you select and use; items attached to your phone's accessory connector; and your voice, data, and other application usage patterns.

Caution: To prevent injuries or burns, do not allow metal objects to contact or short-circuit the battery terminals.

To maximise your battery's performance:

- Always use Motorola Original batteries and battery chargers. The phone warranty does not cover damage caused from using non-Motorola batteries and/or battery chargers.
- New batteries or batteries that have been stored for a long time may require a longer charge time.
- Maintain the battery at or near room temperature when charging.
- Do not expose batteries to temperatures below -10°C (14°F) or above 45°C (113°F). Always take your phone with you when you leave your vehicle.
- When you do not intend to use a battery for a while, store it uncharged in a cool, dark, dry place, such as a refrigerator.
- Batteries gradually wear down and require longer charging times. This is normal. If you charge your battery regularly and notice a decrease in talk time or an increase in charging time, then it is probably time to purchase a new battery.



The rechargeable batteries that power this phone must be disposed of properly and may need to be recycled. Refer to your battery's label for battery type. Contact your local recycling centre for proper disposal methods.


Warning: Never dispose of batteries in a fire because they may explode.

Installing the Battery


Note: If necessary, remove the battery from its protective clear plastic case.




Your phone is designed to use only Motorola Original batteries and accessories. We recommend that you store batteries in their protective cases when not in use.



1



2




3

Charging the Battery

New batteries are shipped partially charged. Before you can use your phone, you need to install and charge the battery as described below. Some batteries perform best after several full charge/discharge cycles.

Action

- 1 Plug the travel charger into the bottom of your phone.





-
- 2 Plug the other end of the travel charger into the appropriate electrical outlet.
-
- 3 When your phone indicates **Charge Complete**, remove the travel charger.
-


Tip: You can safely leave the travel charger connected to your phone after charging is complete. This will not damage the battery.

Turning Your Phone On


Action

- 1 Press and hold  for 2 seconds to turn on the phone.



-
- 2 If necessary, enter your SIM card PIN code and press **OK** () to unlock the SIM card.

Caution: If you enter an incorrect PIN code 3 times in a row, your SIM card is disabled and your phone displays SIM Blocked.


-
- 3 If necessary, enter your 4-digit unlock code and press **OK** () to unlock the phone.
-

Adjusting Volume

Press up or down on volume keys to:

- increase or decrease earpiece volume during a call
- increase or decrease the ringer volume setting when the home screen is visible

Tip: At the lowest volume setting, press the down volume key once to switch to vibrate alert. Press it again to switch to silent alert. Press the up volume key to cycle back to vibrate alert, then ring alert.







- turn off an incoming call alert

Alternatively the volume can also be accessed by pressing menu

 > **Settings** > **Ring Styles**.




Making a Call

Press	To
1 keypad keys	dial the phone number
2 	make the call
3 	end the call and “hang up” the phone when you are finished



Alternatively access the Phonebook by pressing menu 
> **Phone Book** > *scroll through to required entry* > **Send** .


Answering a Call

When you receive a call, your phone rings and/or vibrates and displays an incoming call message.

Press	To
1  or ANSWER ()	answer the call
2 	end the call and “hang up” the phone when you are finished

Viewing Your Phone Number

To view your phone number from the home screen, press  .

While you are on a call, press  > **My Tel. Numbers**.

Note: Your phone number must be stored on your SIM card to use this feature. To store your phone number on the SIM card, see page 51. If you do not know your phone number, contact your service provider.

Highlight Features

You can do much more with your phone than make and receive calls! This section describes some of your phone's highlight features.

Taking and Sending a Photo


To activate your phone's camera:

Find the Feature

 > **Multimedia** > **Camera**

Note: Camera can also be accessed quickly by pressing the right Soft Key from idle display, depending on local settings.

The active viewfinder image appears on your display.



Point the camera lens at the photo subject, then:

Press

1 CAPTURE (📷)

To

take a photo

2 STORE (📁)

view storage options

If you choose to store the photo, continue to step 3.

or

DISCARD (🗑️)

delete the photo and return to the active viewfinder

3 (🔄)

scroll to **Send in Message, Store Only, Apply as Wallpaper, or Apply as Screen Saver**

4 SELECT (👉)

perform the storage option of your choice

Press (📷) to open the **Pictures Menu** when the camera is active. The **Pictures Menu** can include the following options:

Option	Description
Go To Pictures	View pictures and photos stored on your phone.
Auto-Timed Capture	Set a timer for the camera to take a photo.
Delete All	Delete all pictures.
Pictures Setup	Open the setup menu to adjust picture settings.
View Free Space	See how much memory remains for storing pictures.

Sending a Multimedia Message



A *Multimedia Messaging Service* (MMS) message contains one or more slides with text and embedded media objects (including photos, pictures, animations, sounds, voice records, and/or video clips). You can send the multimedia message to other wireless phone users, and to email addresses.

Find the Feature












> **Messages** > **New Message**
> **New Multimedia Msg**

Press

To

1	keypad keys	enter slide text
2		open the MMS Menu
3		scroll to Insert
4	SELECT ()	display a list of items you can insert
5		scroll to Picture, Voice Record, Sound, Video, Quick Note, Contact Info, or MMS Templates
6	SELECT ()	select the file type
7		highlight the file you want
8	INSERT ()	insert the file To add another slide to the message, continue. To send the message, go to step 14.
9		open the MMS Menu to insert a new slide
10		scroll to Insert
11	SELECT ()	display a list of items you can insert


Press	To
12 	scroll to New Page
13 SELECT ()	insert a new slide after the current slide Repeat steps 1 to 8 to enter contents for the new slide.
14 OK ()	store the message
15 	scroll to a Send To option: <ul style="list-style-type: none"> • Highlight [One Time Entry] to enter one or more phone numbers and/or email addresses. • Highlight [New Phonebook Entry] to enter a number/address and add it to the phonebook. • Or highlight an existing phonebook entry.
16 SELECT ()	select [One Time Entry] or [New Phonebook Entry] and enter a number/address
or	
ADD ()	add a phonebook entry to the list of recipients
17 DONE ()	store the numbers/addresses
18 	scroll to Subject
19 CHANGE ()	select Subject
20 keypad keys	enter the subject



Press	To
21 OK (↵)	store the subject
22 SEND (↵)	send the message

Receiving a Multimedia Message



When you receive a multimedia message or letter, your phone displays the  (message waiting) indicator and a **New Message** notification, and sounds an alert.

Press	To
READ (↵)	open the message

Multimedia messages that you receive can contain different media objects:

- Photos, pictures, and animations are displayed as you read the message.
- A sound file or video clip begins playing when its slide is displayed. Use the volume keys to adjust the volume as the sound file or video clip plays.

Note: *In a multimedia letter, you may have to highlight an indicator in the text to play a sound file or video clip.*

- Attached files are added to the end of the message. To open the attachment, highlight the file indicator/filename and press **VIEW** (↵) (image file type), **PLAY** (↵) (sound file or video clip), or **OPEN** (↵) (object such as phonebook or datebook entry, or unknown file type).

Playing Video Clips

You can download video clips with the micro-browser, and send and receive video clips in multimedia messages.

To play a video clip stored on your phone:

Find the Feature



> **Multimedia** > **Videos**

Press

To


1

scroll to the video clip

2 **PLAY** ()

start video clip playback

The video clip displays in the video clip playback screen.





Learning to Use Your Phone

See page 1 for a basic phone diagram.



Using the Display

The *home screen* displays when you are *not* on a call or using the menu. You must be in the home screen to dial a phone number.



Press the 5-way navigation key (⊙) left, right, up, or down to select one of the menu feature icons. If you select a menu icon by mistake, press  to return to the home screen.


Note: Your home screen may look different from the display shown above. For example, your service provider may hide the menu feature icons to allow a better view of the wallpaper image. You can still select the menu icons when they are hidden from view. To show or hide the menu icons, see page 76.

The  (menu) indicator indicates that you can press the menu key () to enter the main menu.



Labels at the bottom corners of the display show the current soft key functions. Press the left soft key (⏪) or right soft key (⏩) to perform the function indicated by the left or right soft key label.

Your phone can display an analogue or digital clock in the home screen (see page 75).

The following status indicators can display:




1. Signal Strength Indicator


Vertical bars show the strength of the network connection. You cannot make or receive calls when the  (no signal) indicator or  (no transmit) indicator displays.

2. GPRS Indicator




Shows that your phone is using a high-speed General Packet Radio Service (GPRS) network connection. GPRS allows faster data transfer speeds. Indicators can include:


 = GPRS PDP context active


 = GPRS packet data available


3. Data Transmission Indicator


Shows connection and data transmission status. Indicators can include:

 = secure packet data transfer

 = insecure packet data transfer

 = secure application connection

 = insecure application connection

 = secure Circuit Switch Data (CSD) call

 = insecure CSD call

4. Roam Indicator



Shows when your phone is seeking or using another network outside your home network. Indicators can include:

 = 2.5G home



 = 2.5G roam




 = 2G home

 = 2G roam

5. Active Line Indicator









Shows  or  to indicate the current active phone line. Other indicators can include:


-  = line 1 active, call divert on  = line 2 active, call divert on
 = alarm activated

6. Messaging Presence Indicator



Shows when Instant Messaging (IM) is active. Indicators can include:






-  = IM active  = available for IM
 = busy  = invisible to IM
 = available for phone calls  = offline

When a Java application is active, a  (Java midlet) indicator can display in this location.

7. Message Indicator



Displays when you receive a new message. Indicators can include:

-  = text message  = voicemail message
 = IM message  = active chat session
 = voicemail and text message

When you enter a message, a number in this location shows the number of characters left on the current page (text message), or the message size (multimedia message or letter).

8. Location Indicator




Your phone may be able to send location information to the network during an emergency call. Indicators show when your phone is sending location information:

 = location on

 = location off

9. Ring Style Indicator


Shows the ring style setting.

 = loud ring

 = soft ring

 = vibrate

 = vibrate and ring


 = silent

10. Battery Level Indicator

Vertical bars show the battery charge level. Recharge the battery when **Low Battery** displays and the battery alert sounds.


Using the 5-Way Navigation Key


Use the 5-way navigation key (⊙) to scroll up, down, left, or right through the menu system, highlight menu items, change feature settings, and play games. Press the centre select button to select a highlighted menu item. The centre select button usually performs the same function as the right soft key (⏪).













Using Menus

From the home screen, press  to enter the main menu.



Press  to scroll to and highlight a menu feature icon in the main menu. The following icons represent features that may display in the main menu, depending on your service provider and service subscription options.

Icon	Feature	Icon	Feature
	Games & Apps		Multimedia
	Office Tools		Settings
	IM		Web Access
	Phonebook		Recent Calls
	Messages		Chat




Selecting a Menu Feature

To select a menu feature, starting from the home screen:

Find the Feature




> **Recent Calls** > **Dialled Calls**

This example shows that from the home screen, you must press , scroll to and select  **Recent Calls** from the main menu, then scroll to and select **Dialled Calls**. Press  to scroll, and the left/right soft keys to select the functions displayed in the bottom left and right corners of the display.

Selecting a Feature Option

Some features require you to select an option from a list:



Press (DIRECTIONAL PAD) to scroll up or down to highlight the option you want.

In a numbered list, press a number key to highlight the option.


In an alphabetised list, press a key repeatedly to cycle through the letters on the key and highlight the closest matching list option.

When an option has a list of possible values, press (DIRECTIONAL PAD) left or right to scroll through and select a value.


When an option has a list of possible numeric values, press a number key to set the value.

Entering Text

Some features require you to enter information.




The message centre lets you compose and send text messages. A *Character Counter* indicates how many more characters will fit in the message.



Choosing a Text Entry Method

Multiple text entry methods make it easy for you to enter names, numbers, and messages. The method (for example, iTAP predictive text or TAP input mode) you select remains active until you select another method.

Press  in any text entry screen to select one of the following entry methods:

Primary


The primary text entry method (see below to set).

Numeric


Enter numbers only (see page 43).

Symbol	Enter symbols only (see page 44).
Secondary	The secondary text entry method (see below to set).

Alternatively, you can select a text entry method in any text entry screen by pressing  > **Entry Mode**.


Tip: You can switch between text Entry Methods by pressing  whilst in edit mode.

Setting Up a Text Entry Method

Press  > **Entry Setup** from any text entry screen. Select **Primary Setup** or **Secondary Setup**, and choose:

ITAP	Let the phone predict each word as you press keys (see page 42).
Tap	Enter letters and numbers by pressing a key one or more times.
Tap Extended	Enter letters, numbers, and symbols by pressing a key one or more times.
None	Hide the Secondary setting (only available for Secondary Setup).

Using Capitalisation

Press  in any text entry screen to change text case. The following indicators show capitalisation status:

abc = no capital letters

Abc = capitalise next letter only

ABC = all capital letters

Text Entry Method Indicators

When you select the **Primary** or **Secondary** text entry method, the following indicators identify the text entry setting:

Primary	Second.	
1	2	Tap, no capital letters
1↑	2↑	Tap, capitalise next letter only
1↑↑	2↑↑	Tap, all capital letters
👉	👉	iTAP, no capital letters
👉↑	👉↑	iTAP, capitalise next letter only
👉↑↑	👉↑↑	iTAP, all capital letters





The following indicators identify Numeric or Symbol entry method:


123 = numeric method @ = symbol method

Using Tap Method


This is the standard method for entering text on your phone.

Tap method cycles through the letters and number of the key you press. Tap Extended method also cycles through additional symbols as shown in the chart on page 41.

Press	To
1 A keypad key one or more times	select a letter, number, or symbol
2 keypad keys	enter remaining characters. Tip: Press  right to accept a word completion, or  to insert a space.
3  ()	store the text

In a text entry screen, you can press  to switch entry methods. If **Tap** or **Tap Extended** is not available as the **Primary** or **Secondary** entry method, see page 38.

When you enter text with **Tap** or **Tap Extended** method, the soft key functions change.















When you enter 3 or more characters in a row, your phone may guess the rest of the word. For example, if you enter **prog** you might see:




If you want a different word (such as **progress**), continue pressing keypad keys to enter the remaining characters.




Character Chart

Use this chart as a guide for entering characters with **Tap Extended** method.

	.?! , @ ' - _ : ; () & " ~ 1 0 ç ÿ % £ \$ ¥ ¤ € + x * / \ [] = > < # §
	a b c 2 á à â ã ç æ
	d e f 3 é è ê ë
	g h i 4 í î ï
	j k l 5
	m n o 6 ñ ó ô õ ö ø
	p q r s 7
	t u v 8 ú û ü
	w x y z 9
	change text case, for capital letters
	enter a space (hold to enter a return)
	change text entry method (hold for default)

Note: This chart may not reflect the exact character set available on your phone. In an email address or URL editor,  first shows common characters for that editor.


Tap Method Text Entry Rules

- Press a keypad key repeatedly to cycle through its characters.
- Press  left or right to move the flashing cursor to the left or right in a text message.
- The first character of every sentence is capitalised. If necessary, press  down to force the character to lowercase before the cursor moves to the next position.
- If you enter or edit information and do not want to save the changes, press  to exit without saving.

Using iTAP™ Method


iTAP² software provides a predictive text entry method that lets you enter a word using one keypress per letter. This can be faster than **Tap** method, because your phone combines the keypresses into common words.



For example, if you press    , letter combinations that match your keypresses display:



If you want a different word (such as **Progress**), continue pressing keypad keys to enter the remaining characters.

Entering Words

In a text entry screen, you can press  to switch entry methods. An indicator shows which method is active (see page 39). If iTAP method is not available as the **Primary** or **Secondary** entry method, see page 38.

Press	To
1 keypad keys (one press per letter)	show possible letter combinations at the bottom of the display
2  left or right	highlight the combination you want
3 SELECT 	lock a highlighted combination

You can press keypad keys to add more letters to the end of the combination.

or





enter the highlighted combination when it spells a word

A space is automatically inserted after the word.


If you enter a word your phone does not recognise, the phone stores it to use as one of your word options. When you fill memory space for unrecognised words, your phone deletes the oldest words to add new words.

Using Numeric Method

In a text entry screen, press  to switch entry methods until the ¹²³ (numeric) indicator displays.


Press keypad keys to enter the numbers you want. When you finish entering numbers, press  to switch to another entry method.

Using Symbol Method

In a text entry screen, press  to switch entry methods until the @ (symbol) indicator displays.

Press

1 keypad keys (one press per symbol)

2  left or right

3 **SELECT** ()

To

show possible symbol combinations at the bottom of the display

highlight the combination you want

lock a highlighted combination

You can press keypad keys to add more symbols to the end of the combination.









or








enter the highlighted combination

Symbol Chart

Use this chart as a guide for entering characters with symbol method.

	.?! , @ ' - _ : ; () & " ~ 1 0 ÷ ¡ % £ \$ ¥ ¤ € + x * / \ [] = > < # §
	@ _ \ ß
	/ : ;
	" & '
	() [] { }
	¿ ¡ ~
	< > =
	\$ £ ¥ ¤

	# % *
	+ - x * / = > < # §
	enter a space (hold to enter a return)
	change text entry method (hold for default)

Note: This chart may not reflect the exact character set available on your phone. In an email address or URL editor,  first shows common characters for that editor.

Deleting Letters and Words


Place the cursor to the right of the text you want to delete, and then:

Action

Press **DELETE** () to delete one letter at a time.

Hold **DELETE** () to delete the entire message.

Using the Smart Key

The smart key gives you another way to perform many basic phone functions. It anticipates the next action you are likely to perform. For example, when you highlight a menu item, you can press the smart key to select it. You can use the smart key to make and end calls, turn features on and off, and open your phonebook. The smart key usually performs the same function as the right soft key ()


Using the External Display


When the flip is closed, the external display shows time and phone status information. It also displays messages to notify you of incoming calls and other events. See page 27 for descriptions of the status indicators that may appear in the external display.

Note: You cannot make or receive calls when the phone is closed unless you attach a headset.

Using the Handsfree Speaker

When you activate your phone's built-in handsfree speaker, you can talk to the other party without holding the phone to your ear.

Press **SPEAKER** () to turn the handsfree speaker on or off during a call.

When you turn the handsfree speaker on, your phone displays **Spkrphone On** in the home screen. The handsfree speaker remains on until you press **SPEAKER** () again or turn the phone off.

Note: *The handsfree speaker is disabled when you connect your phone to a handsfree car kit or headset accessory.*

Changing a Code, PIN, or Password

Your phone's 4-digit unlock code is originally set to 1234, and the 6-digit security code is originally set to 000000. Your service provider may reset these codes before you receive your phone.

If your service provider has not reset these codes, we recommend that you change them to prevent others from accessing your personal information. The unlock code must contain 4 digits, and the security code must contain 6 digits.

You can also reset your SIM card PIN code, PIN2 code, and/or call barring password if necessary.

To change a code or password:

Find the Feature



> **Settings** > **Security**
> **New Passwords**

Locking and Unlocking Your Phone

You can lock your phone manually or set the phone to lock automatically whenever you turn it off.

To use a locked phone, you must enter the unlock code. A locked phone still rings or vibrates for incoming calls or messages, but you must unlock it to answer.

You can make emergency calls on your phone even when it is locked (see page 59).

Locking Your Phone Manually

Find the Feature



> **Settings** > **Security**
> **Phone Lock** > **Lock Now**

Press

1 keypad keys

2 **OK** (⏏)

To

enter your unlock code

lock the phone

Unlocking Your Phone

Your phone's unlock code is originally set to 1234. Your service provider may reset the unlock code to the last 4 digits of your phone number.

At the **Enter Unlock Code** prompt:

Press

1 keypad keys

2 **OK** (⏏)

To

enter your unlock code

unlock your phone

Setting Your Phone to Lock Automatically

You can set your phone to lock every time you turn it off:

Find the Feature



> **Settings** > **Security**
> **Phone Lock** > **Automatic Lock**
> **On**

Press

1 keypad keys

To

enter your unlock code

2 **OK** (⏏)

activate automatic lock

If You Forget a Code, PIN, or Password

Your phone's 4-digit unlock code is originally set to 1234, and the 6-digit security code is originally set to 000000. Your service provider may reset the unlock code to the last 4 digits of your phone number before you receive your phone.

If you forget your unlock code, try entering 1234 or the last 4 digits of your phone number. If that does not work, at the **Enter Unlock Code** prompt:

Press

1 

To

display the unlock code bypass screen

2 keypad keys

enter your security code

3 **OK** (⏏)

submit your security code

If you forget your security code, SIM card PIN code, PIN2 code, or call barring password, contact your service provider.

Using the Phonebook

This section briefly describes basic phonebook operations. For more information about using the phonebook, see page 73.

Storing a Phone Number

Enter a phone number in the home screen, then press **STORE** (☐) to create a phonebook entry with that number. Fill in the other fields to complete the entry.

Select **MORE** to store another number (for example, a work number) under the same Name.

Recording a Voice Name

When creating a phonebook entry, scroll to **Voice Name** and press **RECORD** (☐). Press and release the voice key and say the entry's name (within 2 seconds). When prompted, press and release the voice key and repeat the name. Press **DONE** (☐) to store the voice name.

Note: This option is not available for entries stored on the SIM card.

Storing a Picture for Caller ID


You can store a picture for a phonebook entry. The picture appears when you receive calls from the entry.





Note: This option is not available for entries stored on the SIM card.

When creating a phonebook entry, scroll to **Picture** and press **CHANGE** (☐). Press (☉) to select a picture, and press **SELECT** (☐) to store it for the entry.

Dialling a Number

Press  > **Phonebook** > *entry to call* .



Note: You can also access the Phonebook from idle display by pressing , depending on local settings.

Tip: To quickly highlight entries in your **Phonebook** list: If your entries are sorted by Speed No., press an entry's speed number to highlight it. For example, press   for entry number 15. If your entries are sorted by **Name**, **Voice Name**, or **Email**, enter the first letter of the entry's name to highlight it. For example, press   for the first entry that starts with "K".

Voice Dialling a Number



Press and release the voice key, and say the entry's name (within 2 seconds).

Sorting Phonebook Entries

Press  > **Phonebook**, press  > **Setup** > **Sort by**, then select whether you want to sort the phonebook list by **Name**, **Speed No.**, **Voice Name**, or **Email**.

When sorting by name, you can view **All** numbers or just the **Primary** number for each name. To set the primary number for a name, see page 74.

Viewing Entries By Category

Press  > **Phonebook**, press  > **Categories**, then select whether you want to view **All** entries, entries in a predefined category (**Business**, **Personal**, **General**, **VIPs**), or entries in a category you created.

To set the category for a phonebook entry, see page 74.

Setting Up Your Phone

Storing Your Name and Phone Number





To store or edit your name and phone number information on your SIM card:

Find the Feature



> **Settings** > **Phone Status**
> **My Tel. Numbers**

Shortcut: Press   from the home screen to edit your name and phone number.

If you do not know your phone number, contact your service provider.

Setting the Time and Date

Your phone uses the time and date for the **Datebook**. Your phone can synchronise its time and date with the network:

Find the Feature



> **Settings** > **Initial Setup**
> **Time and Date** > **Autoupdate**
> **On**

To set the time and date manually, set **Autoupdate** to **Off** and use the **Time** and **Date** options:

Find the Feature



> **Settings** > **Initial Setup**
> **Time and Date** > **Time or Date**

Setting a Ring Style

Your phone rings or vibrates to notify you of an incoming call or other event. This ring or vibration is called an *alert*.

You can select one of five different ring styles. The ring style indicator in the display shows the current ring style (see page 31).

To set a ring style:

Find the Feature



> **Settings** > **Ring Styles** > **Style**

Press

1

To

scroll to the ring style

2 **SELECT** ()

select the ring style

Each ring style contains settings for specific event alerts, ringer ID, and ringer and keypad volume. To change these settings, press

> **Settings** > **Ring Styles** > *style Detail*.

Setting Answer Options

You can use additional, alternative methods to answer an incoming call.

Multi-Key

answer by pressing any key

Open to Answer





answer by opening the phone

To activate or deactivate an answer option:

Find the Feature



> **Settings** > **In-Call Setup**
> **Answer Options**

Press	To
1 	scroll to Multi-Key or Open to Answer
2 CHANGE ()	select the option
3 	scroll to On or Off
4 SELECT ()	confirm the setting







Setting a Wallpaper Image

You can set a photo, picture, or animation as a wallpaper (background) image in your phone's home screen. The wallpaper image appears as a faint watermark in text and menu displays.

Find the Feature



> **Settings** > **Personalise**
> **Wallpaper**

Press	To
1 	scroll to Picture
2 CHANGE ()	open the picture viewer
3  up or down	scroll to a picture/animation Scroll to (None) to turn off the wallpaper image.
4 SELECT ()	select the image
5 	scroll to Layout
6 CHANGE ()	adjust the image layout

Press

7 

To

scroll to **Centre**, **Tile**, or **Fit-to-screen**

Centre places the image in the centre of the display.

Tile fills the display with multiple copies of the image.

Fit-to-screen resizes the image, if necessary, to fit the display.

8 **SELECT** 

confirm the layout setting

9 **BACK** 

save wallpaper settings

Setting a Screen Saver Image

Set a photo, picture, or animation as a screen saver image.

The screen saver image displays when the phone is on and no activity is detected for a specified time. The image shrinks to fill the display, if necessary. An animation repeats for one minute, then the first frame of the animation displays.

Turn off the screen saver to extend battery life.

Find the Feature



> **Settings** > **Personalise**
> **Screen Saver**

Press


1 

To

scroll to **Picture**

2 **CHANGE** 

open the picture viewer






3  up or down

scroll to a picture/animation

Scroll to **[None]** to turn off the screen saver image.

4 **SELECT** 

select the image

Press	To
5 	scroll to Delay
6 CHANGE 	set the delay interval
7 	scroll to the inactivity interval that triggers the screen saver
8 SELECT 	confirm the delay setting
9 BACK 	save screen saver settings

Setting Display Contrast

Find the Feature



> **Settings** > **Initial Setup**
> **Contrast**

Setting Display Colour

Select the colour palette that your phone uses to display indicators, highlights, and soft key labels.

Find the Feature



> **Settings** > **Personalise**
> **Colour Style**

Adjusting the Backlight

Set the amount of time that the display and keypad backlights remain on.

Find the Feature



> **Settings** > **Initial Setup**
> **Backlight**

Setting Display Timeout

Set the display to turn itself off when no activity is detected for a specified time.

Find the Feature



> **Settings** > **Initial Setup**
> **Display Timeout**

Calling Features

For basic instructions on how to make and answer calls, see page 19.

Changing the Active Line



Change the active phone line to make and receive calls from your other phone number.

Note: This feature is available only for dual-line-enabled SIM cards.

Find the Feature



> **Settings** > **Phone Status**
> **Active Line**

The active line indicator in the display shows the currently active phone line (see page 30).

Redialling a Number

Press

1

2

3

To

view the last 10 dialled calls list

scroll to the entry you want to call

redial the number

Using Automatic Redial



When you receive a busy signal, your phone displays **Call Failed, Number Busy**.

To redial the phone number:

Press

 or **RETRY** ()

To

activate automatic redial

Your phone automatically redials the number. When the call goes through, your phone rings or vibrates one time, displays **Redial Successful**, and then connects the call.

Using Caller ID

Incoming Calls



Calling line identification (Caller ID) displays the phone number for incoming calls in your phone's display.

The phone displays the caller's name (and picture, if available) when the name is stored in your phonebook, or **Incoming Call** when caller ID information is not available.

Outgoing Calls



You can show or hide your phone number as an ID for the calls that you make.

Find the Feature



> **Settings > In-Call Setup**

> **My Caller ID**

You can override the default caller ID setting when you make a call. While dialling (with digits visible in the display):

Press

 > **Hide ID/Show ID**

To

hide or show your caller ID for the next call

Canceling an Incoming Call

While the phone is ringing or vibrating:

Press

IGNORE ()

To

cancel the incoming call



Depending on your phone settings and/or service subscription, the call may be diverted to another number, or the caller may hear a busy signal.

Turning Off a Call Alert

You can turn off your phone's incoming call alert before answering the call.

Press

either volume key

To

turn off the alert

Calling an Emergency Number

Your service provider programmes one or more emergency phone numbers, such as 999, that you can call under any circumstances, even when your phone is locked or the SIM card is not inserted.

Emergency numbers vary by country. Your phone's preprogrammed emergency number(s) may not work in all locations, and sometimes an emergency call cannot be placed due to network, environmental, or interference issues.

Press

1 keypad keys


To

dial the emergency number

2 


call the emergency number

Dialling International Numbers

Press and hold  to insert the local international access code (+) for the country from which you are calling.

Viewing Recent Calls

Your phone keeps lists of the calls you recently received and dialled, even if the calls did not connect. The lists are sorted from newest to oldest entries. The oldest entries are deleted as new entries are added.

Shortcut: Press  from the home screen to view the dialled calls list.

Find the Feature> **Recent Calls****Press**1 **To**scroll to **Received Calls** or **Dialled Calls**2 **SELECT** ()

select the list

3 


scroll to an entry

✓ means the call connected.

4 

call the entry's number

or

Press and hold  for 2 seconds to send the number as DTMF tones during a call.

Press

VIEW 

or



To

view entry details

open the **Last Calls Menu** to perform various operations on the entry




The **Last Calls Menu** can include the following options:

Option	Description
Store	Create a phonebook entry with the number in the No. field.
Delete	Delete the entry.
Delete All	Delete all entries in the list.
Hide ID/Show ID	Hide or show your caller ID for the next call.
Send Message	Open a new text message with the number in the To field.
Add Digits	Add digits after the number.
Attach Number	Attach a number from the phonebook or recent calls lists.
Send Tones	Send the number to the network as DTMF tones. This option displays only during a call.
Talk then Fax	Talk and then send a fax in the same call (see page 80).

Returning an Unanswered Call





Your phone keeps a record of your unanswered calls, and displays:

- **X Missed Calls**, where **X** is the number of missed calls

Press	To
1 VIEW 	see the received calls list
2 	select a call to return
3 	make the call

Using the Notepad

The most recent set of digits entered on the keypad are stored in your phone's notepad memory. This can be a phone number that you called, or a number that you entered but did not call. To retrieve the number stored in the notepad:

Find the Feature	 > Recent Calls > Notepad
Press	To
	call the number
or	
	open the Dialling Menu to attach a number or insert a special character
or	
STORE 	create a phonebook entry with the number in the No. field

Attaching a Number

While dialling (with digits visible in the display):

Press



 > **Attach Number**

To

attach a number from the phonebook or recent calls lists

Calling With Speed Dial

Each entry you store in your phonebook is assigned a unique speed dial number.

To see an entry's speed dial number, press  > **Phonebook**, scroll to the entry, press **VIEW** (.

To speed dial a phonebook entry:

Press

1 keypad keys

To

enter the speed dial number for the entry you want to call

2



submit the number

3



call the entry

Calling With 1-Touch Dial

To call phonebook entries 1 to 9, press and hold the single-digit speed dial number for one second.

Tip: You must specify which phone number list you want to use with this feature: phone memory phonebook or SIM card phonebook (see page 74).

Using Voicemail



Voicemail messages that you receive are stored on the network. To listen to your messages, you must call your voicemail phone number.

Your service provider may include additional information about using this feature.

Listening to Voicemail Messages


Find the Feature



> **Messages** > **Voicemail**

The phone calls your voicemail phone number. If no voicemail number is stored, your phone prompts you to store a number.

Receiving a Voicemail Message

When you receive a voicemail message, your phone displays the  (voicemail message) indicator and a **New Voicemail** notification.

Press

CALL (☎)

To

listen to the message

The phone calls your voicemail phone number. If no voicemail number is stored, your phone prompts you to store a number.

Storing Your Voicemail Number

If necessary, use the following procedure to store your voicemail phone number on your phone. Usually, your service provider has already done this for you.

Find the Feature



> **Messages**



> **Voicemail Setup**



Press	To
1 keypad keys	enter your voicemail number
2 OK (⏏)	store the number

You cannot store a **p** (pause), **w** (wait), or **n** (number) character in this number. If you want to store a voicemail number with these characters, create a phonebook entry for it. Then, you can use the entry to call your voicemail.

Using Call Waiting



When you are on a call, an alert tone sounds to indicate that you have received a second call.

Press	To
1 	answer the new call
2 SWITCH (⏏)	switch between calls
or	
LINK (⏏)	connect the 2 calls
or	
 > End Call On Hold	end the call on hold

You must turn on call waiting to use the feature. To turn call waiting on or off:

Find the Feature




> **Settings** > **In-Call Setup**
> **Call Waiting**

Putting a Call On Hold

Press

HOLD (☎) (if available)

or

 > **Hold**

To

put the call on hold

Transferring a Call



You can announce that you are transferring an active call to another party, or you can directly transfer the call.

Announce the Call Transfer

Find the Feature

 > **Hold**

Press

1 keypad keys

To

dial the number where you are transferring the call

2



call the number and speak to the person who answers

3



open the menu

4



scroll to **Transfer**

5



select **Transfer**

6



confirm the transfer

Do Not Announce the Call Transfer

Find the Feature



> Transfer

Press

1 keypad keys

To

dial the number where you are transferring the call

2



transfer the call

Phone Features

Menu Map

Main Menu

 **Phonebook**

 **Recent Calls**

- Received Calls
- Dialed Calls
- Notepad
- Call Times
- Call Cost
- Data Times
- Data Volumes

 **Messages**

- Create Message
- Message Inbox
- Voicemail
- Browser Msgs
- Info Services
- Quick Notes
- Outbox
- Drafts
- MMS Templates

 **Office Tools**

- SIM Tool Kit Apps *
- Calculator
- Datebook
- Shortcuts
- Alarm Clock
- Chat
- Dialling Services
 - Fixed Dial
 - Service Dial *
 - Quick Dial *

 **Games & Apps**

 **Web Access**

- Browser
- Web Shortcuts
- Stored Pages
- History
- Go To URL
- Browser Setup
- Web Sessions

 **Multimedia**

- Themes
- Camera
- Pictures
- Sounds
- MotoMixer
- Videos

 **IM**

- Log In
- Offline Convs.
- Offline Settings
- Help

 **Settings**

- (see next page)

* optional features

This is the standard main menu layout. Menu organisation and feature names may vary on your phone. Not all features may be available on your phone.

Settings Menu



Personalise

- Home Screen
- Main Menu
- Colour Style
- Greeting
- Wallpaper
- Screen Saver
- Quick Dial



Ring Styles

- Style
- Loud Detail



Call Divert

- Voice Calls
- Fax Calls
- Data Calls
- Cancel All
- Divert Status



In-Call Setup

- In-Call Timer
- Call Cost Setup
- My Caller ID
- Talk and Fax
- Answer Options
- Call Waiting



Initial Setup

- Time and Date
- 1-Touch Dial
- Display Timeout
- Backlight
- Scroll
- Language
- Contrast
- DTMF
- Master Reset
- Master Clear



Phone Status

- My Tel. Numbers
- Credit Info/Available *
- Active Line
- Battery Meter
- Other Information



Headset

- Auto Answer
- Voice Dial



Car Settings

- Auto Answer
- Auto Handsfree
- Power-off Delay
- Charger Time



Network

- New Network
- Network Setup
- Available Networks
- My Network List
- Service Tone
- Call Drop Tone



Security

- Phone Lock
- Lock Application
- Fixed Dial
- Call Barring
- SIM PIN
- New Passwords



Java Settings




- Java App Loader
- Java System
- Delete All Apps
- App Vibration
- App Volume
- App Priority
- App Backlight

* optional features




Feature Quick Reference







This section helps you locate features on your phone that are not described in this guide.

Calling Features






Feature	Description	
Conference Call	During a call: ☰ > Hold , dial next number, press ☏, press LINK (☏)	
Call Diverting	Set up or cancel call diverting: ☰ > Settings > Call Divert	
Call Barring	Restrict outgoing or incoming calls: ☰ > Settings > Security > Call Barring	




Messages

Feature	Description	
Send Text Message	Send a text message: ☰ > Messages > New Message > New Short Msg	
Send Multimedia Message	Send a multimedia message: ☰ > Messages > New Message > New Multimedia Msg	
Send Letter	Send a multimedia letter: ☰ > Messages > New Message > New Letter	




Feature	Description	
Use MMS Template	Open an MMS template with preloaded media:  > Messages > New Message > MMS Templates	
Read Message	Read a new text or multimedia message that you have received: Press READ ().	
Store Message Objects	Go to a multimedia message slide, or highlight an object in a letter, then:  > Store	

Instant Messaging







Feature	Description	
Log In	Log in to instant messaging:  > IM > Log In	
Find Others Online	After you log in: Select Contact List to see a list of other users.	
Start Conversation	Start a conversation: From your Contact List , highlight a name in Online Contacts , press SEND IM ().	












Feature	Description	
Open Active Conversation	Open a conversation in progress: From your Contact List , highlight a name in Conversations , press VIEW (⏏).	
End Conversation	From the conversation display: ⏏ > End Conversation	
Log Out	Log out of instant messaging: Select Log Out from the IM Online menu.	

Chat








Feature	Description	
Start Chat	Start a new chat session: ⏏ > Chat ⏏ > New Chat	
Receive Chat Request	When you receive a chat request: Press ACCEPT (⏏) or IGNORE (⏏).	
End Chat	During a chat session: ⏏ > End Chat	





Phonebook

Feature	Description
Create Entry	Create a new phonebook entry: Type in telephone number > Store > <i>enter other details</i>
Create Group Mailing List	Create a group mailing list as a phonebook entry:  > Phonebook  > New > Mailing List
Dial Number	Call a number stored in the phonebook:  > Phonebook , highlight the phonebook entry, press  to call
Voice Dial Number	Voice dial a number stored in the phonebook: Press and release the voice key, and say the entry's name (within 2 seconds).
Set Ringer ID for Entry	Assign a distinctive ringer alert to a phonebook entry:  > Phonebook > <i>entry</i>  > Edit > Ringer ID > <i>ringer name</i> Note: The Ringer ID option is not available for entries stored on the SIM card.




Feature	Description
Set Picture ID for Entry	Assign a picture to display when you receive calls from an entry:  > Phonebook > <i>entry</i>  > Edit > Picture > <i>picture</i> Note: The Picture option is not available for entries stored on the SIM card.
Set Category for Entry	Set the category for a phonebook entry:  > Phonebook > <i>entry</i>  > Edit > Category > <i>category name</i> Note: The Category option is not available for entries stored on the SIM card.
Set Category View	Set a phonebook category view:  > Phonebook  > Categories > <i>category view</i>
Sort Phonebook List	Set the order in which phonebook entries are listed:  > Phonebook  > Setup > Sort by > <i>sort order</i>
Set Primary Number	Set the primary number for a phonebook entry with multiple numbers:  > Phonebook , scroll to entry, press  > Set Primary > <i>phone number</i>
1-Touch Dial	Set 1-touch dial to call entries stored in your phone memory phonebook or the SIM card phonebook:  > Settings > Initial Setup > 1-Touch Dial

Personalising Features








Feature	Description
Ring Style	Change the ring alert for an event:  > Settings > Ring Styles > <i>style Detail</i> > select chosen alerts
Ringer IDs	Activate distinctive ring alerts assigned to phonebook entries:  > Settings > Ring Styles > <i>style Detail</i> > Ringer IDs
Ring Volume	Set ringer volume:  > Settings > Ring Styles > <i>style Detail</i> > Ring Volume
Keypad Volume	Set keypad keypress volume:  > Settings > Ring Styles > <i>style Detail</i> > Key Volume
Clock View	Display an analogue clock or digital time readout in the home screen:  > Settings > Personalise > Home Screen > Clock
Menu View	Display the main menu as graphic icons or as a text-based list:  > Settings > Personalise > Main Menu > View
Main Menu	Reorder your phone's main menu:  > Settings > Personalise > Main Menu > Reorder



Feature	Description
Show or Hide Menu Icons	Show or hide menu feature icons in the home screen:  > Settings > Personalise > Home Screen > Home Keys > Icons
Change Home Screen Keys & Icons	Change soft key labels, smart key function, and menu feature icons in the home screen:  > Settings > Personalise > Home Screen > Home Keys
Shortcuts	Create a shortcut to a menu item: Highlight the menu item, then press and hold  . Select a shortcut:  > Office Tools > Shortcuts > <i>shortcut name</i>

Menu Features


Feature	Description
Language	Set menu language:  > Settings > Initial Setup > Language
Master Reset	Reset all options except unlock code, security code, and lifetime timer:  > Settings > Initial Setup > Master Reset
Master Clear	Reset all options except unlock code, security code, and lifetime timer, and clear all user settings and entries except SIM card information:  > Settings > Initial Setup > Master Clear

Dialling Features





Feature	Description
Fixed Dial	<p>When you turn on fixed dialling, you can call only numbers stored in the fixed dial list. </p> <p>Turn fixed dialling on or off:</p> <p> > Settings > Security > Fixed Dial</p> <p>Use the fixed dial list:</p> <p> > Office Tools > Dialling Services > Fixed Dial</p>
Service Dial	<p>Dial service phone numbers: </p> <p> > Office Tools > Dialling Services > Service Dial</p>
Quick Dial	<p>Your service provider may programme your phone with one or more quick dial numbers, such as the customer service number. </p> <p>Dial preprogrammed phone numbers:</p> <p> > Office Tools > Dialling Services > Quick Dial</p>



Feature	Description
DTMF Tones	<p>Activate DTMF tones:</p> <p> > Settings > Initial Setup > DTMF</p> <p>Send DTMF tones during a call:</p> <p>Press number keys.</p> <p>Send stored numbers as DTMF tones during a call:</p> <p>Highlight a number in the phonebook or recent calls lists, then press  > Send Tones.</p>

Call Monitoring

Network connection time is the elapsed time from the moment you connect to your service provider's network to the moment you end the call by pressing . This time includes busy signals and ringing.









The amount of network connection time you track on your resettable timer may not equal the amount of time for which you are billed by your service provider. For billing information, contact your service provider.



Feature	Description
Call Times	<p>View call timers:</p> <p> > Recent Calls > Call Times</p> 
In-Call Timer	<p>Display time or cost information during a call:</p> <p> > Settings > In-Call Setup > In-Call Timer</p> 

Feature	Description
Call Cost	View call cost information:  > Recent Calls > Call Cost 

Handsfree Features



Note: The use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products.

Feature	Description
Speaker-phone	When in an active call, press SPEAKER (). 
Auto Answer (car kit or headset)	Automatically answer calls when connected to a car kit or headset:  > Settings > Car Settings or Headset > Auto Answer 
Voice Dial (headset)	Enable voice dial with headset send/end key:  > Settings > Headset > Voice Dial 
Auto Handsfree (car kit)	Automatically route calls to a car kit when connected:  > Settings > Car Settings > Auto Handsfree 

Feature	Description
Power-Off Delay (car kit)	Set the phone to stay on for a specified time after the ignition is switched off:  > Settings > Car Settings > Power-Off Delay
Charger Time (car kit)	Charge the phone for a specified time after the ignition is switched off:  > Settings > Car Settings > Charger Time




Data and Fax Calls

Feature	Description
Send Data or Fax	Connect your phone to the device, then place the call through the device application.
Receive Data or Fax	Connect your phone to the device, then answer the call through the device application.
Talk Then Fax	Connect your phone to the device, enter the number, then press  > Talk Then Fax  to make the call.

















Network Features

Feature	Description
Network Settings	View network information and adjust network settings:  > Settings > Network





Personal Organiser Features



Feature	Description
Create Datebook Event	Create a new datebook event:  > Office Tools > Datebook , highlight the day, press the centre select button, press  > New
View or Edit Datebook Event	View or edit event details:  > Office Tools > Datebook , highlight the day, press the centre select button, press VIEW ()
Event Reminder	View event reminder: VIEW () Close event reminder: BACK ()
Set Alarm	Set an alarm:  > Office Tools > Alarm Clock
Turn Off Alarm	Turn off alarm: Press DISABLE () or  . Set 8-minute delay: Press SNOOZE ()

Feature	Description
Calculator	Calculate numbers:  > Office Tools > Calculator
Currency Converter	Convert currency:  > Office Tools > Calculator  > Exchange Rate Enter exchange rate, press OK () , enter amount, and select \$ in the bottom of the display.







Security

Feature	Description
SIM PIN	Lock or unlock the SIM card:  > Settings > Security > SIM PIN Caution: If you enter an incorrect PIN code 3 times in a row, your SIM card is disabled and your phone displays SIM Blocked .
Lock Application	Lock phone applications:  > Settings > Security > Lock Application

News and Entertainment

Feature	Description
Launch Micro-Browser	Start a micro-browser session:  > Web Access > Browser 

Feature	Description
Download Objects from Web Page	Download a picture, sound, or phone theme from a Web page: Highlight the file, press SELECT (⏏), press STORE (⏏). 
Web Sessions	Select or create a Web session:  > Web Access > Web Sessions 
Apply Phone Theme	Apply a grouped set of image and sound files to your phone:  > Multimedia > Themes > theme 
Download Game or Application (micro-browser)	Download a Java game or application with the micro-browser:  > Web Access > Browser , highlight the application, press SELECT (⏏), press DOWNLOAD (⏏) 
Download Game or Application (computer)	Download a Java game or application from a computer: Connect your phone to the computer, press  > Settings > Java Settings > Java App Loader . 
Launch Game or Application	Launch a Java game or application:  > Games & Apps , highlight the application, press SELECT (⏏) 
Manage Pictures	Manage pictures and animations:  > Multimedia > Pictures 

Feature	Description
Manage Sounds	Manage ring tones, sounds that you have composed or downloaded:  > Multimedia > Sounds
Manage Video Clips	Manage video clips:  > Multimedia > Videos
Edit Sounds With MotoMixer	Edit MIDI-based sound files that you can use with your phone:  > Multimedia > MotoMixer > [New Mix] or mix file name
Create Ring Tones	Create ring tones that you can use with your phone:  > Multimedia > Sounds > [New iMelody]
Camera	When in camera mode, scroll up and down to zoom in and out () and from right to left to adjust the level of brightness. To change other settings press  > Picture Setup .

Specific Absorption Rate Data

This model phone meets international standards for exposure to radio waves

Your mobile phone is a radio transmitter and receiver. It is designed and manufactured not to exceed limits for exposure to radio frequency (RF) energy. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organisations through periodic and thorough evaluation of scientific studies. The guidelines include a substantial safety margin designed to assure the safety of all persons, regardless of age and health.

The exposure standard for mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. Under the guidelines for your phone model, the SAR limit is 2.0 W/kg.¹ Tests for SAR are conducted in accordance with CENELEC² testing procedures using standard operating positions with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a base station, the lower the power output of the phone.

Before a phone model is available for sale to the public, it is tested to confirm compliance with the guidelines. The tests are performed in positions that conform to a uniform testing methodology determined by an expert standards body. The highest SAR value for this model phone when tested for use at the ear is: 0.90 W/kg.³

While there may be differences between the SAR levels of various phones and at various positions, they all meet the governmental requirements for safe exposure. Please note that improvements to this product model could cause differences in the SAR value for later products; in all cases, products are designed to be within the guidelines.

- 1 The SAR limit recommended by international guidelines (ICNIRP) for mobile phones used by the public is 2.0 watts/kilogram (W/kg) averaged over ten grams of tissue. The limit incorporates a substantial margin for safety to give additional protection for the public and to account for any variations in measurements.
- 2 CENELEC is a European Union standards body.
- 3 Additional related information includes the Motorola testing protocol, assessment procedure, and measurement uncertainty range for this product.

Index

A

- accessories 13
- accessory connector port 1
- active line indicator 30
- active line, changing 57
- alarm clock 81
- alert
 - creating 84
 - defined 52
 - setting 18, 52, 75
 - turning off 19, 59
- animation
 - downloading 83
 - screen saver 54
 - viewing 83
 - wallpaper 53
- answering a call 19, 52
- application, locking and
 - unlocking 82
- automatic redial 58

B

- backlight 55
- barring calls 70
- battery
 - charging 17

- extending battery life 14, 55
 - installing 16
 - level indicator 31
- browser. See micro-browser

C

- calculator 82
- call
 - alert, turning off 19, 59
 - answer options 52
 - answering 19
 - barring 70
 - barring password, changing 46
 - call waiting 65
 - costs 79
 - dialled calls list 60
 - dialling 19
 - diverting 70
 - emergency number 59
 - ending 19
 - handsfree speaker 46
 - hold 66
 - international access code 60
 - making 19
 - received calls list 60
 - receiving 19

- ring style 18, 52, 75
- speakerphone 79
- timers 78
- transferring 66
- unanswered call 62
- Call Failed, Number Busy
 - message 58
- call waiting 65
- caller ID 22, 58
- calling line identification. *See* caller ID
- camera
 - settings 84
 - taking a photo 21
- category
 - phonebook entry 74
 - view 74
- centre select button 32
- character chart 41
- chat 72
- clock
 - selecting analogue or digital 75
 - setting 51
- codes
 - changing 46
 - default 46, 48
 - forgetting 48
- colour, setting 55
- conference call 70

- contrast, setting 55
- customising the menu 75

D

- data call 80
- date, setting 51
- datebook 81
- dialled calls list 60
- dialling a number 19, 77
- display
 - backlight 55
 - colour 55
 - contrast 55
 - description 27
 - home screen 27
 - language 76
 - personalising 76
 - timeout 56
- distinctive ringer alert 75
- diverting calls 70
- DTMF tones
 - activating 78
 - sending 78

E

- earpiece volume 18
- emergency number 59
- end key 1
- ending a call 19

Enter Unlock Code message
47

external display 45

F

fax call 80

5-way navigation key 1, 32

fixed dial 77

G

games 83

GPRS indicator 29

groove tunes 84

H

handsfree speaker 46

headset jack 1

hold a call 66

home keys, personalising 76

home screen

defined 27

selecting clock view 75

I

IM 71

incoming call

answering 19

diverting 70

Incoming Call message 58

indicators

active line 30

battery level 31

GPRS 29

Java midlet 30

location 31

message 30

message waiting 25

messaging presence 30

ring style 31

roam 29

signal strength 28

text case 39

text entry method 30, 39

transmission 29

voicemail message 30, 64

instant messaging. See IM

international access code 60

iTAP software 42

J

Java applications 83

Java midlet indicator 30

joystick 1

K

key

centre select button 32

end 1

5-way navigation 1, 32

- left soft key 1, 28, 76
- menu 1
- power 1
- right soft key 1, 28, 76
- send 1
- smart 45
- voice 1
- volume control 1, 18

keypad

- answering calls 52
- volume, setting 75

L

- language, setting 76
- left soft key
 - functions 1, 28
 - personalising 76
- line, changing 57
- location indicator 31
- lock
 - application 82
 - phone 47
 - SIM card 82
- Low Battery message 31

M

- making a call 19
- master clear 76
- master reset 76

- menu
 - entering text 36
 - icons, changing in home screen 76
 - icons, converting to text 75
 - icons, showing or hiding 76
 - language, setting 76
 - personalising 75
 - rearranging features 75
 - using 33
 - view, changing 75
- menu key 1
- message
 - chat 72
 - MMS template 71
 - MMS, defined 23
 - multimedia letter 70
 - multimedia message 70
 - reading 71
 - text 70, 71
- message indicator 30
- message waiting indicator 25
- messaging presence indicator 30
- micro-browser
 - browser setup 83
 - Java applications 83
 - using 82
 - Web sessions 83
- MMS template 71

MMS. See message
MotoMixer 84
multimedia letter, sending 70
multimedia message
 receiving 25
 sending 23, 70
multimedia messaging service.
 See message
my telephone number 20, 51

N

network settings 81
notepad 62
number
 storing your number 51
 viewing your number 20
numbers, entering 43

O

1-touch dial
 setting preference 74
 using 63
open to answer 52
optional accessory, defined 13
optional feature, defined 13

P

passwords. See codes
phone
 active line indicator 30

 active line, changing 57
 alert, turning off 19, 59
 answer options 52
 clear stored information 76
 codes 46
 date, setting 51
 keypad, answering calls 52
 language, setting 76
 locking 47
 network settings 81
 open to answer 19
 reset all options 76
 ring style 18, 52, 75
 security code 46
 time, setting 51
 turning on/off 18
 unlock code 46
 unlocking 18, 47

phone number

 active line indicator 30
 active line, changing 57
 attaching 2 numbers 63
 international access code 60
 redialling 57
 storing in phonebook 73
 storing your number 51
 viewing your number 20

phone theme 83

phonebook

 attaching 2 numbers 63

- category for entry 74
- category view 74
- dialling a number 73
- group mailing list 73
- 1-touch dial 63
- picture ID 22, 49, 58, 74
- primary number, setting 74
- ringer ID 73, 75
- sorting entries 50, 74
- speed dial number 63
- storing an entry 73
- voice dialling 73
- photo
 - downloading 83
 - picture ID 22, 58
 - sending 21
 - taking 21
- picture
 - downloading 83
 - screen saver 54
 - viewing 83
 - wallpaper 53
- picture ID 22, 58
 - setting 49, 74
- PIN code
 - changing 46
 - entering 82
- PIN2 code, changing 46

- power key 1
- predictive text entry 42
- primary text entry method 37

Q

- quick dial 77

R

- received calls list 60
- recent calls 60
- redial
 - automatic redial 58
 - busy number 57
- right soft key
 - functions 1, 28
 - personalising 76
- ring style indicators 31
- ring style, setting 18, 52, 75
- ring tone
 - creating 84
 - downloading 83
 - editing with MotoMixer 84
 - managing 84
- ringer ID
 - setting 73
 - turning on/off 75
- ringer volume, setting 18, 75
- roam indicator 29

S

- screen saver 54
- secondary text entry method 37
- security code
 - changing 46
 - default 46
- send key 1
- service dial 77
- shortcuts 76
- signal strength indicator 28
- silent alert, setting 18, 52, 75
- SIM Blocked message 18, 82
- SIM card
 - defined 13
 - installing 13
 - locking 82
 - PIN code entry 18
 - PIN code, changing 46
 - PIN2 code, changing 46
 - precautions 13
 - SIM Blocked message 18, 82
- SIM PIN code
 - changing 46
 - entering 82
- SIM PIN2 code, changing 46
- smart key 45
- soft keys
 - functions 28

- illustration 1
- personalising 76
- sound
 - creating 84
 - downloading 83
 - managing 84
- Speaker On message 46
- speakerphone
 - activating 79
 - automatic answer 79
- speed dial 63
- standby time, increasing 55
- symbol chart 44
- symbols, entering 44

T

- tap method text entry 39
- telephone number
 - storing your number 51
 - viewing your number 20
- text
 - capitalisation, changing 38
 - character chart 41
 - entering 36
 - entry method, selecting 37
 - entry method, setup 38
 - iTAP software predictive text entry 42
 - numeric method 43
 - symbol chart 44

- symbol method 44
- tap method 39
- text case indicator 39
- text entry method
 - selecting 37
 - setup 38
- text entry method indicator 30, 39
- theme 83
- time, setting 51
- timers 78
- transfer a call 66
- transmission indicator 29
- travel charger 17

U

- unlock
 - application 82
 - phone 47
- unlock code
 - bypassing 48
 - changing 46
 - default 46, 48
 - entering 18

V

- vibrate alert
 - setting 18, 52, 75
 - turning off 19, 59

- video clip
 - downloading 71
 - managing 84
 - playing 26
- voice dial 73, 79
- voice key
 - dialling a number 73
 - illustration 1
- voicemail 64
- voicemail message indicator 30, 64
- volume
 - earpiece 18
 - keypad 75
 - ringer 18, 75
- volume keys 1, 18

W

- wallpaper 53
- Web pages 82
- Web sessions 83
- Welcome 1

6809479A58